

EA-1
E-CORE

If the E-Core does not seat exactly the same as it did when the balance was checked and adjusted at the factory, the balance could give the impression that the stops need adjusting. The problem is caused by the E-Core being tipped slightly from front to back with respect to the beam.

Always make sure that the E-Core is properly positioned on its mounting.